
















Assembly Instructions

Ventilator Portable Bar Stool with Arms

DREAMSEAT

1. Back (1x) 	7. Bolts (4x)  m8*1-1/2"
2. Seat (1x) 	8. Bolts (8x)  m6*3/4"
	9. Allen Wrench (1x)  m6
3. Frame (1x Set)  LEFT RIGHT	10. Allen Wrench (1x)  m8
4. Footrest (1x) 	11. Nuts (4x) 
	12. Armrest (1x Set)  Left Right
5. Bolts (2x)  m8*4"	13. Bracket (2x) 
1. Bolts (2x)  m8*2"	14. Washer (2x) 
	15. Screws (4x)  M4x1"

Do not fully tighten all bolts until assembly is complete. This will help all parts assemble properly.

