















Assembly Instructions

Ventilator Portable Bar Stool without Arms

DREAMSEAT

1. Back (1x) 	7. Bolts (4x)  m8*1-1/2"
2. Seat (1x) 	8. Bolts (8x)  m6*3/4"
3. Frame (1x Set)  LEFT RIGHT	9. Allen Wrench (1x)  m6 10. Allen Wrench (1x)  m8
4. Footrest (1x) 	11. Nuts (4x) 
5. Bolts (2x)  m8*4"	12. Bracket (2x) 
1. Bolts (2x)  m8*2"	13. Washer (2x) 
	14. Screws (4x)  M4x1"

Do not fully tighten all bolts until assembly is complete. This will help all parts assemble properly.

